

DuPont™ Kalrez® Spectrum™ 7090 Perfluoroelastomer Parts

O-rings for glass tube manufacturing

The process to manufacture pharmaceutical glass container tubes starts with long glass tubes which are heated, bended, and cut through with specialized equipment. Due to its high thermal conductivity, metal can damage the glass at high temperatures. To avoid damage during manufacturing when the tubes are rotated by a stainless steel wheel, an O-ring is used on the outside to avoid direct contact between the steel wheel and the glass tube.

- **Chemicals and cleaning:** Hot air
- **Process conditions:** Max. 230 °C
- **Incumbent solution:** Silicone O-rings
- **Performance challenge:** Insufficient lifetime (max. 1 week) due to thermal degradation. The O-rings leave marks on the glass.
➔ Rejection of the tubes

Kalrez® Spectrum™ 7090 benefits:

- Kalrez® Spectrum™ 7090 seal allowed to extend the MTBR (Mean Time Between Repair) to more than six months.
- This high temperature resistant material significantly reduced downtime driven by frequent part replacement. The use of Kalrez® parts also reduced scrap by minimizing reject material in the customer's production line which also boosted plant yield.



The performance is based on tests performed by the customer. Since conditions of use are outside DuPont's control, DuPont assumes no liability in connection with any use of this information. This data should not be used to establish specification limits.

Visit us at [kalrez.com](https://www.kalrez.com)

The information set forth herein is furnished free of charge, is based on technical data that DuPont believes to be reliable and represents typical values that fall within the normal range of properties. This information relates only to the specific material designated and may not be valid for such material used in combination with other materials or in other processes. It is intended for use by persons having technical skill, at their own discretion and risk. This information should not be used to establish specification limits nor used alone as the basis of design. Handling precaution information is given with the understanding that those using it will satisfy themselves that their conditions of use present no health or safety hazards and comply with applicable law. Since conditions of product use and disposal are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any product, evaluation under end use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate or a recommendation to infringe on patents.

CAUTION: Do not use DuPont materials in medical applications involving implantation in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract that is consistent with the DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your DuPont representative.

DuPont's sole warranty is that our products will meet our standard sales specifications in effect at the time of shipment. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, DUPONT SPECIFICALLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR NON-INFRINGEMENT. DUPONT DISCLAIMS LIABILITY FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

DuPont™, the DuPont Oval Logo, and all trademarks and service marks denoted with ™, ® or © are owned by affiliates of DuPont de Nemours, Inc. unless otherwise noted. © 2022 DuPont. All rights reserved.

(02/2022) Reference: KZE-A40110-00-0222